







Parts Breakdown

LS1016

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	265995-6	TAPPING SCREW 4X18, BO4556K	2
2	450999-3	REAR COVER, LS1016	1
3	631863-9	CONTROLLER, LS1016	1
4	265995-6	TAPPING SCREW 4X18, BO4556K	2
5	664463-0	CORD (2X14X8 SJ), 5007F	1
6	687052-4	STRAIN RELIEF, 5007F	1
7	866468-8	NAME PLATE, LS1016	1
8	266095-5	TAPPING SCREW 5X55, KP0810	2
9	318399-2	MOTOR BRACKET, LS1016	1
10	451001-5	BAFFLE PLATE, LS1016	1
11	961057-5	RETAINING RING S-17, LS1016L	1
12	210301-0	BALL BEARING 6003DDW, RT0700C	1
	211275-8	BALL BEARING 6003DDW, 9741	
13	240001-8	FAN 80, LS1016L	1
14	517821-8	ARMATURE ASS'Y 115V, LS1016	1
15	681642-5	INSULATION WASHER, LS1016L	1
16	211062-5	B. BEARING 6000ZZ, LS1016L	1
17	596346-5	FIELD ASS'Y 115V, LS1016	1
18	158958-8	MOTOR HOUSING CPL., LS1016	1
19	643650-4	BRUSH HOLDER CAP, 5007F	2
20	CB154	CARBON BRUSH SET, 194986-9	1
	194986-9	CARBON BRUSH SET, 194986-9	
	181047-4	CARBON BRUSH SET 154,5402A	
21	911948-0	PAN HEAD SCREW M6X80 LS1016	4
22	451015-4	COVER, LS1016	1
23	265995-6	TAPPING SCREW 4X18, BO4556K	6
24	450998-5	HANDLE COVER, LS1016	1
26	451003-1	SWITCH LEVER, LS1016	1
27	650618-3	SWITCH TG72B-1, LS1016	1
28	416356-5	LOCK-OFF LEVER, LS1016L	1
29	231026-3	COMP. SPRING 4, LS1016L	1
30	265995-6	TAPPING SCREW 4X18, BO4556K	2
31	140036-8	HANDLE CPL., LS1016	1
32	265995-6	TAPPING SCREW 4X18, BO4556K	2
33	451037-4	SWITCH BUTTON, LS1016	1
34	451017-0	COVER HOLDER, LS1016	1
35	265995-6	TAPPING SCREW 4X18, BO4556K	1
36	451004-9	LEAD COVER, LS1016	1
37	231928-3	RING SPRING 8, LS1016L	1
38	256633-1	PIN 6, LS1016L	1
39	231240-1	COMP. SPRING 7, LS1016L	1
40	911113-1	P.H. SCREW M4X10, LS1016L	2
41	262001-8	RING 5, LS1016L	1
42	265717-4	SCREW M6X43, LS1016L	1
43	266488-6	HEX SOCKET HEAD BOLT M8X20, LS1016L	1
44	922332-4	HEX. SOCKET HEAD BOLT M6X20, LS1016L	1
	922331-6	H.S.H. BOLT M6X20, LS1016L	
45	687095-6	STRAIN RELIEF, LS1016L	1
46	266026-4	TAPPING SCREW 4X12, LS1016L	1
47	419277-0	DUST NOZZLE, LS1016L	1
48	213460-9	O RING 35, LS1016L	1
49	266321-2	HSS SCREW(FLAT POINT) M6X16, LS1016	1
50	922331-6	H.S.H. BOLT M6X20, LS1016L	1
51	253804-1	F. WASHER 6, LS1016L	1
52	257163-5	RING 6, LS1016L	1
53	158960-1	LINK PLATE CPL., LS1016	1
54	257163-5	RING 6, LS1016L	1
55	253804-1	F. WASHER 6, LS1016L	1



Parts Breakdown

LS1016

56	961018-5	STOP RING E-5, LS1016L	1
57	911113-1	P.H. SCREW M4X10, LS1016L	1
58	346050-4	GUARD HOLDER, LS1016L	1
59	231675-6	TORSION SPRING 11, LS1016	1
60	453634-2	GUARD, LS1016L	1
	451006-5	GUARD, LS1016L	
61	325645-6	GUARD SHAFT, LS1016	1
62	265324-3	H.F.H. BOLT M8X12, LS1016L	1
63	140055-4	BLADE CASE CPL., LS1016	1
64	210005-4	BALL BEARING 608DDW, LS1016L	1
65	961052-5	RETAINING RING S-12, LS1016L	1
66	253744-3	F. WASHER 12, LS1016L	1
67	261104-5	RUBBER WASHER12, LS1016	1
68	253744-3	F. WASHER 12, LS1016L	1
69	227550-2	SPIRAL BEVEL GEAR 32, LS1016L	1
70	254001-2	WOODRUFF KEY 4, LS1016L	1
71	266026-4	TAPPING SCREW 4X12, LS1016L	2
72	451002-3	GREASE HOLDER, LS1016	1
73	227701-7	HELICAL GEAR 14, LS1016	1
74	227702-5	HELICAL GEAR 27, LS1016	1
75	216024-8	STEEL BALL 4, LS1016L	1
76	325643-0	GEAR SHAFT, LS1016	1
77	211062-5	B. BEARING 6000ZZ, LS1016L	1
78	210005-4	BALL BEARING 608DDW, LS1016L	1
79	961055-9	RETAINING RING S-15, 5007F	1
80	227703-3	HELICAL GEAR 28, LS1016	1
81	442147-8	GASKET, LS1016L	1
82	911223-4	P.H. SCREW M5X16, 5007MG	3
83	210005-4	BALL BEARING 608DDW, LS1016L	1
84	267010-2	F. WASHER 5, LS1016L	1
85	942101-7	SPRING WASHER 5, 9005B	1
86	931202-6	HEX NUT M5, LS1016L	1
87	285847-5	BEARING RETAINER 14-23, LS1016L	1
88	158957-0	BEARING BOX CPL., LS1016L	1
89	211236-8	BALL BEARING 6002DDW, LS1016L	1
90	325644-8	SPINDLE, LS1016	1
91	285732-2	BEARING RETAINER 51, LS1016L	1
92	265034-2	C.S.H. SCREW, LS1016L	2
93	224428-0	INNER FLANGE 46, LS1016	1
94	224429-8	OUTER FLANGE 46, LS1016	1
95	265405-3	H.F.H. BOLT M10X20, LS1016L	1
96	158959-6	SAFETY COVER A CPL., LS1016	1
97	231634-0	TORSION SPRING 45, LS1016L	1
98	424190-9	CUSHION, LS1016	1
99	265985-9	HEX.SOCKET HEAD BOLT M6, LS1016L	1
100	346048-1	CENTER COVER, LS1016	1
101	253932-2	W. WASHER 10, LS1016L	1
102	344539-6	CENTER WASHER, LS1016L	1
103	346047-3	CENTER PLATE, LS1016	1
104	266034-5	TAPPING SCREW 4X16, LS1016L	1
105	266020-6	TAPPING SCREW 4x12, BO4556	2
106	941051-3	F. WASHER 4, LS1016L	2
107	424193-3	ROLER, LS1016L	2
108	451754-6	SAFETY COVER B, LS1016L	1
	451005-7	SAFETY COVER B, LS1016	
109	266026-4	TAPPING SCREW 4X12, LS1016L	3
122	451016-2	BLADE CASE COVER, LS1016	1
123	266034-5	TAPPING SCREW 4X16, LS1016L	1
124	451038-2	PROTECTOR, LS1016	1
127	265026-1	P.H. SCREW M4, LS1016L	2
128	941102-2	F. WASHER 5, LS1016L	2



Parts Breakdown

LS1016

129	233267-7	COMPRESSION SPRING 7, LS1016L	2
130	941102-2	F. WASHER 5, LS1016L	2
131	272261-4	LEVER 45, LS1016L	2
132	325651-1	JOINT, LS1016L	2
133	253804-1	F. WASHER 6, LS1016L	2
134	158970-8	UPPER FENCE R CPL., LS1016	1
135	346058-8	GUIDE PLATE, LS1016	2
136	318596-0	LOWER FENCE R, LS1016	1
	318415-0	LOWER FENCE R, LS1016	
137	265783-1	THUMB SCREW M6X18, LS1016L	1
138	318411-8	GUIDE FENCE, LS1016	1
139	922443-5	HSH BOLT M8X25 WITH WR, LS1016	4
140	256226-4	PIN 4, LS1016L	2
141	266264-8	H.S.H.SCREW M5X8, LS1016L	2
142	265783-1	THUMB SCREW M6X18, LS1016L	1
143	318595-2	LOWER FENCE L, LS1016	1
	318413-4	LOWER FENCE L, LS1016L	
144	158969-3	UPPER FENCE L CPL., LS1016	1
145	346049-9	STOPPER ARM, LS1016	1
146	253948-7	W. WASHER 8, LS1016L	1
147	253835-0	F. WASHER 8, LS1016L	1
148	251267-5	P.H. SCREW M6, LS1016L	1
149	451036-6	SLEEVE 17, LS1016	1
150	323740-6	ROD 16, LS1016L	1
151	271601-3	KNOB 20, LS1016L	1
152	213021-5	O RING 5, JR3070CT	1
153	324183-5	STOPPER PIN, LS1016L	1
154	233537-4	TORSION SPRING, LS1016	1
155	266026-4	TAPPING SCREW 4X12, LS1016L	1
156	158962-7	STOPPER LEVER CPL., LS1016	1
157	158961-9	FRONT ARM CPL., LS1016L	1
158	265783-1	THUMB SCREW M6X18, LS1016L	1
159	231240-1	COMP. SPRING 7, LS1016L	1
160	266034-5	TAPPING SCREW 4X16, LS1016L	1
161	158963-5	ARM CPL., LS1016L	1
162	318403-7	PIPE HOLDER, LS1016	1
163	266208-8	HEX SOCKET HEAD BOLT M6X8, LS1016L	2
164	266026-4	TAPPING SCREW 4X12, LS1016L	1
165	687095-6	STRAIN RELIEF, LS1016L	1
166	911113-1	P.H. SCREW M4X10, LS1016L	1
167	252130-5	HEX LOCK NUT M10, LS1016L	1
168	253024-7	F. WASHER 10, LS1016L	2
169	216413-7	THRUST NEEDLE CAGE 1024, LXSL01	1
170	451019-6	LEVER 105, LS1016	1
171	265589-7	HEX BOLT M10, LS1016	1
172	253024-7	F. WASHER 10, LS1016L	1
173	415208-7	RELEASE BUTTON, LS1016L	1
174	233031-6	COMPRESSION SPRING 12, LS1016L	1
175	266488-6	HEX SOCKET HEAD BOLT M8X20, LS1016L	1
176	318405-3	STOPPER, LS1016	1
177	961052-5	RETAINING RING S-12, LS1016L	1
178	253744-3	F. WASHER 12, LS1016L	1
179	231646-3	TORSION SPRING14, LS1016	1
180	262158-5	RUBBER RING 9, LS1216L	1
	262051-3	RUBBER RING, HR3851	
181	346071-6	PLATE, LS1016	1
182	266488-6	HEX SOCKET HEAD BOLT M8X20, LS1016L	1
183	451008-1	ARM COVER, LS1016	1
184	266034-5	TAPPING SCREW 4X16, LS1016L	1
185	343678-9	INDICATION PLATE, LS1016L	1
186	266034-5	TAPPING SCREW 4X16, LS1016L	1



Parts Breakdown

LS1016

187	158964-3 140376-4 158964-3	ARM HOLDER CPL., LS1016 N/A ARM HOLDER CPL., LS1016	1
188	266488-6	HEX SOCKET HEAD BOLT M8X20, LS1016L	1
189	961011-9	STOP RING E-4, LS1016L	1
190	451044-7	CAM, LS1016	1
191	325656-1	ROD 6, LS1016	1
192	272262-2	LEVER 22, LS1016	1
193	911113-1	P.H. SCREW M4X10, LS1016L	1
194	234122-6	COMPRESSION SPRING 6, LS1016	1
195	325865-2 325655-3	LOCK PIN 8, LS1216L LOCK PIN 8, LS1016	1
196	232250-1	LEAF SPRING, LS1016	1
197	325646-4	CENTER SHAFT, LS1016	1
198	451039-0	POSITION PLATE, LS1016	1
199	451070-6	ARM HOLDER COVER, LS1016	1
200	266034-5	TAPPING SCREW 4X16, LS1016L	1
201	158967-7	SQUARE ROD CPL., LS1016	1
202	925251-3	HEX. BOLT M5X30, LS1016L	2
203	266026-4	TAPPING SCREW 4X12, LS1016L	4
204	451013-8	KERF BOARD, LS1016L	2
205	265585-5	HEX BOLT M8X45, LS1016	1
206	253762-1	F. WASHER 8, LS1016L	1
207	158966-9	TURN BASE CPL., LS1016	1
208	266026-4	TAPPING SCREW 4X12, LS1016L	1
209	451009-9	INDICATION PLATE, LS1016	1
210	451011-2	RACK BLOCK, LS1016	1
211	266385-6	TAPPING SCREW 4X14, GA7021	1
212	941051-3	F. WASHER 4, LS1016L	1
213	266026-4	TAPPING SCREW 4X12, LS1016L	1
214	346052-0	SLIDE LOCK PLATE, LS1016	1
215	286275-7	CAP, 5007MG	1
216	961013-5	STOP RING E-7, LS1016L	1
217	313165-2	CAM, LS1016	1
218	231131-6	COMP. SPRING 11, LS1016	1
219	267047-9	F. WASHER 10, LS1016L	1
220	273666-1	GRIP 50, LS1016	1
221	318410-0	PIN HOLDER, LS1016	1
222	266034-5	TAPPING SCREW 4X16, LS1016L	4
223	451010-4	LOCK LEVER, LS1016L	1
224	345272-3	LOCK LEVER PLATE, LS1016L	1
225	266034-5	TAPPING SCREW 4X16, LS1016L	2
226	266505-2	HS BINDING HEAD SCREW M6X14, LS1016	1
228	346051-2	MITER LOCK PLATE, LS1016	1
229	234104-8	COMPRESSION SPRING 13, LS1016	1
230	266306-8	SHOULDER SCREW M5, LS1016L	1
231	231325-3	COMPRESSION SPRING 6, LS1016L	1
232	256158-5	PIN 3, LS1016L	1
233	325649-8	LOCK PIN 6, LS1016	1
234	158968-5	LINEAR BEARING BOX CPL., LS1016	1
235	451018-8	SPUR GEAR 43, LS1016	1
236	232249-6	LEAF SPRING, LS1016	1
237	266026-4	TAPPING SCREW 4X12, LS1016L	1
238	922441-9	H.S.H. BOLT M8X25, LS1016L	3
239	421845-7	FOOT, LS1016	4
240	267195-4	FLAT WASHER 4, LS1016	4
241	266026-4	TAPPING SCREW 4X12, LS1016L	4
242	158965-1	BASE CPL., LS1016	1
243	810492-3	CAUTION LABEL, LS1016	1
245	810491-5	CAUTION LABEL, LS1016	1
246	817283-3	CAUTION LABEL, LS1016L	1



Parts Breakdown

LS1016

247	816920-6	MITER SCALE PLATE, LS1016L	1
248	451012-0	SLIDE PLATE, LS1016	1
249	266026-4	TAPPING SCREW 4X12, LS1016L	3
250	266034-5	TAPPING SCREW 4X16, LS1016L	1
251	232075-3	LEAF SPRING, LS1016L	1
252	817283-3	CAUTION LABEL, LS1016L	1
253	810487-6	CAUTION LABEL, LS1016	1
254	257785-1	SLEEVE 6, LS1016	1
255	922226-3	H. S. H. BOLT M5X18, LS1016L	1
256	216024-8	STEEL BALL 4, LS1016L	2
257	253874-0	F. WASHER 4, LS1016L	1
258	266042-6	TAPPING SCREW BIND CT 4X20, LS1016L	1
	942151-2	SPRING WASHER 6, 5007NB	1
	253313-0	THIN WASHER, 4340FCT	1
	122852-0	DUST BAG ASS'Y, LS1016	1
	122854-6	VERTICAL VISE ASS'Y, LS1016L	1
	762001-3	TRIANGLE RULE, LS1016L	1
	251889-1	KNOB M5X16, LS1016L	2
	325673-1	HOLDER 200, LS1016L/LS1216L	2
	782232-8	BOX WRENCH 13, LS1016	1
	A-95043	N/A	1
	A-93675	10X5/8 60T MITER SAW BLADE, LS1016L	